

## Maintenance

### General Recommendations

Regular maintenance will improve the performance and extend the life of your Ozark River® portable sink. The portable sink's warranty does not cover items that have been subjected to operator abuse, negligence or freezing. To receive full value from the warranty, the operator must use and maintain the portable sink as instructed in the manual, including proper long-term storage and winterizing.

#### DAILY

1. Clean your sink with non-abrasive cleaners using soft cloth on all surfaces.
2. Wipe or mop up any and all spilled water on, in and around the sink if spillage occurs.
3. Turn sink OFF when not in use.
4. Check Fresh Water level frequently. (Follow level instructions on tank label)
5. Empty Waste Water Tank frequently (Follow level instructions on tank label)
6. Remove any debris from strainer and drain.

#### Weekly

1. Clean faucet aerator of any debris.
2. Inspect Quick Connect cap assembly for cracks or O-ring damage.

#### Biweekly

1. Use Steramine® quaternary sanitizer to clean the drain and hot water system.

### NEVER USE BLEACH TO CLEAN SINK!

### NEVER Operate Portable Sink in Damp or Wet Conditions!

#### Minimum Operating Requirements:

- Dedicated, grounded 110V, 20A circuit breaker per operating system.
- Sinks must be placed on a level, dry surface.
- Extension cords must be rated for 20A or higher (12 gauge wire).
- Water must meet EPA Standards with PH levels between 7.0 - 9.0.



## WINTERIZING

### Your Portable Sink

### Winter or Long Term Storage

**NOTICE:** You must protect your sink from freezing temperatures. Failure to do so will permanently damage your pump and heater system and render your sink inoperable.

### Protect your sink from freezing temperatures:

1. Use Steramine® quaternary sanitizer to clean the drain and hot water system.
2. Turn Sink Power Switch to OFF.
3. Properly dispose of water in Fresh Water and Waste Water tanks according to your state and local health codes.
4. Re-install empty tanks.
5. Turn Sink Power Switch to ON.
6. Turn COLD Water handle to Open position.
7. Turn COLD Water handle open and closed repeatedly until water is gone.
8. Turn HOT Water handle to Open position.
9. Turn HOT Water handle open and closed repeatedly until water is gone.
10. Turn Sink Power Switch to OFF.
11. Wait 2-3 minutes.
12. Repeat steps 5-9 up to two additional times until water is drained from system.
13. Turn Sink Power Switch to OFF.
14. Empty all remaining water from tanks.
15. Disconnect Power Cord from wall outlet.
16. Clean all water and debris from portable sink and wipe with soft cloth.
17. Store portable sink with faucet handles in open position.
18. Store in clean dry area.

**NOTICE:** Should you have any questions about replacing components or need assistance (Support at [www.OzarkRiver.com](http://www.OzarkRiver.com).)